



FCW, LLC
5370 US HWY 77
Cortland, NE 68331
Phone: 402-798-8383
www.fcwguns.com
www.marvelprecision.com
Email: info@fcwguns.com

FCW
Frerking®
Custom Works

GSG Magazine Shim Instructions



Clean back area where shims will be attached with denatured alcohol or acetone. Do this in a well ventilated area. Wait a couple minutes for the surface to dry.

Gently peel the protective backing from the shim. A razor blade is useful to get the edge started then completely remove backing. Be careful to not peel up the adhesive strip. Both are white in color.



Apply first strip by starting it on the tab located on the left side toward bottom of magazine. Make sure the rounded edge of the shim is toward top of magazine.



Apply second shim by lining the bottom of the shim to the same height as the left.

We use a pressure sensitive adhesive so if you gently lay the shims onto the magazine you can move them if needed. Once shims are where you want them press down firmly on them for 10 seconds then let the adhesive setup for 1 hour.

Our shims are oversized so they can be fitted to your magwell. Sand the shims till your magazine falls freely from the pistol when the mag catch is pushed.

Bevel the top edges and sides of the shims to aid in smooth loading into the magwell. A razor blade works well to bevel the shims edges.



Keep cleaning chemicals and oils away from adhesive. If the shim comes loose super glue can be used to bond them in place.

Thanks and enjoy.